

Owner's Manual

YS200


By Dogtra No Bark Collars

Please read this manual thoroughly before using the YS200.


Product Safety and Health Statement

1. The YS200 is intended to prevent the barking of dogs only. It is NOT intended for use on people or on animals other than dogs. Dogtra does not assume any liability for the improper use of the YS200.
2. Leaving the YS200 in the same position on a dog's neck for over 8 hours at a time can cause skin irritation. Occasionally reposition the unit so the contact points are moved to a different location on the dog's neck. Dogtra is not responsible for skin irritation caused by the prolonged usage of the YS200.
3. A proper fit is necessary for the YS200 to work optimally. Both contact points must be in contact with your dog's skin at all times for a consistent stimulation. A loose fitting collar can cause the contact points to rub against the skin and cause irritation.
4. The YS200 is not intended for use on dogs less than 1 year old.
5. Remove the YS200 before playing with your dog. The activity may cause your dog to bark, which could lead to the association of playing to the electrical stimulation.
6. Closely monitor your dog's activity and stimulation output while using the YS200. When attaching or removing the YS200 from your dog's neck, make sure your dog is not barking and in a calm or stable condition.


At a Glance



Overview




Main Features



How to Use the On/Off & Intensity Dial

The ON/OFF and Intensity Dial is used to turn the YS200 on and off, and to select the intensity level. Set the dial to OFF to turn off the YS200. Set the no bark collar to (1) for the lowest stimulation setting and (6) for the highest stimulation setting.




NOTICE

Start with the lowest level of stimulation and work your way up. An appropriate level is when your dog responds to the stimulation with a mild negative reaction, such as a jerking or tensing of the neck muscles.


Testing the YS200

1. Turn the intensity dial to level 2 or 3.
2. Use the cap end of a ballpoint pen and repeatedly tap between the contact points.
3. The unit is working once the LED indicator blinks. Wait 2 seconds and tap again.
4. The unit is in normal working condition when the LED indicator blinks again. The LED indicator will only blink when the unit is activated.




Replacing the Batteries

- *Turn the unit off before attempting to replace the batteries.
- Use a coin to unscrew the battery cover counterclockwise.
- Insert two batteries with the plus sides facing out (both batteries must be facing the same direction).
- Replace the battery cover by screwing it in clockwise. Be sure to place the batteries with the '+' sides facing up and out. To remove the batteries, remove the battery cover and tap the batteries on the palm of your hand.



Extended Contact Points


Extended contact points are available for purchase for dogs with long and/or thick coats. Both contact points must touch your dog's skin and may require longer contact points if your dog has a long and/or thick coat.



Fitting the YS200

It is important to have a proper fit for safe and consistent results.

- Place the YS200 to the left or right of your dog's vocal cords.
- Both contact points must touch your dog's skin to properly operate.
- When properly fitted, you should be able to fit a finger or two snugly in between the contact points and your dog's skin.



***Caution :** Remove all other collars when using the YS200. Other collars or buckles may cause the YS200 to inadvertently activate.

Troubleshooting Guide

1. My dog has skin irritation.

- This may be due to an improper fit or leaving the collar in the same location for an extended period of time. If your dog exhibits signs of skin irritation, consult with a veterinarian.

2. My dog is not reacting to the YS200.

- Check the LED indicator while testing the unit. If the LED indicator does not come on, the batteries may need to be replaced.
- Tighten the collar strap around your dog's neck if it is too loose and make sure the contact points are held firmly against the dog's skin.
- If your dog has a thick or long coat and you already have the extended contact points, you may need to trim the hair on your dog's neck so that both contact points are touching your dog's skin.

3. I need to clean the YS200.

- To clean the YS200, make sure the battery cover is closed and fully sealed, and wipe down the unit with a damp cloth and some alcohol. Make sure the unit is completely dry before use.

WARRANTY AND REPAIR INFORMATION

1-Year Comprehensive Warranty

Dogtra Company provides the original purchaser with a 1-YEAR WARRANTY for the iQ Pet Series, eF-3000 Gold, RR Deluxe, YS200, YS300, YS500, and YS600. The warranty begins from the date of purchase. For the first year, coverage is for Parts, Labor, and Accessories.

After the first year, the cost of Parts, Accessories, Labor fees, and Shipping fees incurred are the customer's responsibility. Labor fees will be variable depending on the extent of the work required.

To Qualify for the Dogtra Warranty

All products must be registered and/or a proof of purchase is required to initiate repair work under warranty. To register your Dogtra product, log onto our website at www.dogtra.com, click on the warranty registration link, and fill out the required information. Registration must be completed within 30 days of purchase. If you do not have access to a computer, you can call our toll free number at 1-888-811-9111, and one of our customer service representatives will register the product for you. If you were unable to register your product within 30 days of purchase, we will accept all products for repair with a proof of purchase. We strongly recommend keeping the original receipt. If your product is not registered and a proof of purchase is not available at the time of service, Dogtra will estimate the age of the unit by the serial number. Serial number estimates can differ from the actual purchase date. A serial number estimate is the only method of determining an approximate date of purchase without product registration or a proof of purchase.

Not Covered Under Warranty

Dogtra DOES NOT offer warranty for products that have been bought secondhand or as a resold product. Dogtra DOES NOT replace defective units or provide refunds for products purchased from us after 30 days from the date of purchase. Dogtra DOES NOT cover the cost of shipping outside of the Continental United States. Issues of replacement and refunds on units purchased less than 30 days from an authorized dealer must be addressed to the dealer directly. If the products purchased from an authorized dealer are after 30 days from the date of purchase, please send the units to Dogtra for service and repair. Dogtra DOES NOT cover the cost of repairs and replacements due to misuse by the owner or dog, improper maintenance, and/or lost units. Any water damage on the Water Resistant Transmitters of the 175NCP, 180NCP, 200NCP Series, 1400NCP Series, 1500NCP Series, and iQ Pet Series, and the Water Resistant Receivers of the RRS, RRD, and RR Deluxe, will not be covered. All replacement costs for either the transmitter or receiver will be the owner's responsibility. The warranty is void if the unit has been altered or an unauthorized person has damaged the unit while attempting repair work. Battery replacement by the customer during the first year of the 2-year Limited Lifetime Warranty is not recommended. If the customer chooses to replace the batteries, any damage to the unit during the change-out by the owner will void the warranty.

The removal of serial numbers from any Dogtra products will void the warranty. Dogtra reserves the right to retain and discard any parts or accessories that have been found damaged upon replacement and repair.

Procedure for Repair Work

If the unit is malfunctioning, please refer to the "Troubleshooting Guide" in the Owner's Manual and call customer service at 1-888-811-9111, for technical support, before sending it to Dogtra for Service. The cost of shipping products under warranty back to Dogtra is the customer's responsibility. Dogtra is not responsible for units damaged or lost in transition to Dogtra. Dogtra is not responsible for loss of training time or inconvenience while the unit is in for repair work. Dogtra does not provide loaner units or any form of compensation during the repair period. A copy of the sales receipt showing the purchase date may be required before warranty work is initiated. Please include a brief explanation outlining the problem and include your name, address, city/state/zip code, daytime phone number, evening phone number, and email address. Or you can visit our website at www.dogtra.com for a service request form. If the repair costs are not covered under warranty, we will call you for payment information and authorization. For any questions concerning your Dogtra products, call us toll free at 1-888-811-9111, M-F 8:30AM - 4:00PM, Pacific Standard Time, or email us at repair@dogtra.com for specific repair inquiries.

Send repair units to :
Dogtra Company / Repairs
22912 Lockness Avenue,
Torrance, CA 90501
U.S.A.

The diagrams and representations in the manual may differ slightly from the actual product depending on the model type.